

Explore Enyaq 2024

Infotainment

Preheating function ensures battery is at its optimum temperature when charging begins

Two ways to start the preheating process:

- ▶ **Manually** by pressing a button in the central infotainment display
- ▶ **Automatically** on the way to a fast-charging station, based on navigation data

